


CASUAL SHIRT SEWING



- Needle system = DBx1
- Needle size = 9 or 11
- Point style = "R"
- - 1 needle lock stitch machine







- Collar sewing = ———
- Needle system = DBx1
- Needle size = 12 or 14
- Point style = "R"
- - 1 needle lock stitch machine








- Sleeve seaming = →
- Needle system = TVx7
- Needle size = 11 or 12
- Point style = "R"
- Machine type = →
 - 2 needle Chain stitch machine
- Stitch picture = →







- Side seaming = →
- Needle system = TVx7 or DCx27
- Needle size = 11 or 12
- Point style = "R"
- Machine type = →
 - 2 needle Chain stitch / safety stitch machine












- Shirt fronting = →
- Needle system = UO 113
- Needle size = 11 or 14
- Point style = "R"
- Machine type = →
 - 2 needle Chain stitch machine
- Stitch picture = →







- Shirt Button holing = →
- Needle system = DPx5
- Needle size = 11 or 14
- Point style = "R"
- - 1 needle lock stitch machine







- Shirt Button sewing = →
- Needle system = TQx1
- Needle size = 11 or 14
- Point style = "R"

1 needle lock stitch machine









- Needle system = DBx1
- Needle size = 11 or 14
- Point style = "R"
- - 1 needle lock stitch machine
- Stitch picture = →








- Pocket sewing = ———
- Needle system = DBx1
- Needle size = 11 or 14
- Point style = "R"
- - 1 needle lock stitch machine
- Stitch picture = →








- Pocket sewing = ───
- Needle system = DBx1
- Needle size = 11 or 14
- Point style = "R"
- - 1 needle lock stitch machine







- Back yoke sewing = ───
- Needle system = DBx1
- Needle size = 11 or 14
- Point style = "R"

1 needle lock stitch machine





